RAIDON


iR2321 快速安裝導引

產品示意圖與配件表

前視圖



背視圖




- A 2.5"硬碟抽取盒
- ●故障燈號
- ⑥ 7+15 Pin SATA 連結埠X2

- B 2.5"硬碟卡榫按鍵
- ●硬碟指示燈
- 散熱風扇

- 靜音模式切換
- 🕞 風扇連接埠
- RAID 切換

打開包裝外盒後,包裝內容包含下列組件:



- 請先確認相關配件與產品本身是否有受損或是缺少配件,若有任何疑問,請與您的經銷商或業務人員聯絡。
- · 請前往官網 (www.raidon.com.tw) 下載說明書、驅動程式以及其餘相關資源。



V0.1(SEP. 2023)

4.連接 SATA 連接線與電源線。(參照以下圖)







內接主機殼示意圖

- 5.硬體安裝完成。您可開啟電源進行相關設定與應用。
- 6.你的作業系統將會自行辨識硬體,辨識成功後請先完成硬碟格式化,完成後即可使用。

RAID 模式切換設定



Buzzer 切換設定




燈號說明

狀態	藍色LED	紅色LED	蜂鳴器
硬碟閒置	恆亮		
無硬碟/硬碟故障		恆亮	鳴叫
資料存取	恆亮	閃爍	
資料重建(來源)	恆亮		
資料重建(目標)		閃爍	

硬體安裝

請參照以下步驟完成硬體安裝:

1.2.5吋硬碟抽盒的部份,請使用零件包內附的鑰匙解鎖硬碟抽取盒鎖,將頂出按鍵向右推移,硬碟抽取盒把手便會彈開,即可取出抽取盒。



- 2. 安裝 2.5 吋硬碟,請使用 4 顆零件包內附的小顆螺絲加以固定。
- 3. 將硬碟安裝到抽取盒上,將抽取盒放入主機內並關上把手。



產品使用注意事項

- 1. 電腦或伺服器具備SATA I、SATA II或SATA III介面。
- 2. 具備SATA I、SATA II或SATA III介面的硬碟。
- 3. 強烈建議使用iR2321 前先設定好RAID模式(預設值是RAID 1)。
- 4. 在新增或變更RAID模式後需重新啟動產品,以確保完成更新為新的RAID模式。
- 5. 本系統允許使用不同廠牌的硬碟。但如果要獲得更好的效能,我們強烈建議使用相 同廠牌型號的硬碟。
- 6. 安裝硬碟前請先確認所使用的硬碟並無壞軌或是其他問題,以免導致系統損毀或 資料遺失。
- 7. 硬碟格式化後, iR2321的總使用儲存容量或許會與硬碟容量加總後的有所不同。
- 8. 強烈建議除了使用iR2321的資料儲存功能外,請針對重要資料備份到另一個儲存 裝置上或遠端備份,雙重備援您重要的資料。若您儲存在iR2321的資料損毀或遺失 ,RAIDON將不負任何的責任。
- 9.對於初始設置,建議使用兩個同廠牌同型號全新硬碟,如果硬碟不是全新的且在 RAIDbox啟動過程中未被偵測到,請先將此硬碟單獨接上電腦透過作業系統清除 其磁區並重新格式化(具體步驟請查閱作業系統的說明)在裝入RAIDbox即可使用。

感謝您使用 銳銨科技股份有限公司 的產品。

本手冊裡的資訊在出版前雖然已經被詳細確認,但實際產品規格將已出貨時為準;任何的產品規格或相關資訊更新,請您直接上 www.RAIDON.com.tw 網站查詢,或直接與您的業務聯絡窗口聯繫,本公司將不另行通知。

如果您對 銳銨科技 的產品有任何疑問'或是想獲得最新產品訊息、使用手冊或韌體,請您聯絡supporting@raidon.com.tw,我們將儘速回覆您。

RAIDON 為 銳銨科技股份有限公司 旗下品牌之一本說明相關產品內容歸 銳銨科技股份有限公司 版權所有


Status


Blue LED

RAIDON

iR2321 Quick Installation Guide

Package Contents and Product Views






A 2.5"HDD Tray

- Fan Port
- B 2.5"Tray Key Lock & Push Open Button 6 7+15 Pin SATA Connector X2
- Mute Switch

- Cooling Fan
- Fail status indicator LED
- HDD status indicator LED
- Raid Switch

Open the package and you should find the following:





- Please check the product and accessories for any defect or missing parts. If you have any questions, please contact your product supplier.
- Please visit the official website (www.raidon.com.tw) to download user manuals, drivers and other related resources.



V0.1(SEP. 2023)

4. Properly connect SATA cable and power cable from your system to the device.







Internal Case

- 5. Power on your system after hardware installation is completed, and your operating system will automatically detect the hard drives from booting.
- 6. Then follow the steps from your operating system to partition and format the drives when necessary, device will be ready to use once the format is completed.

RAID Mode setting



Buzzer setting



HDD Idle Light On **HDD Fail or Adsent** Light On On **HDD Access** Blinking Light On Rebuilding(Source) Light On Rebuilding(Target) Blinking


Red LED

Buzzer

Hardware Installation

Please follow the instructions below to complete the hardware installation.

1. For the 2.5" HDD tray, please use the key included in the accessory kit to unlock the 2.5" HDD tray key lock and push the HDD eject button to the right, the 2.5" HDD tray handle will pop up to remove the tray.



- 2. Install the 2.5-inch hard disk and secure it with the small screws included in the 4 parts package
- 3.When the HDD/SSD installation has been completed, insert the hard drive tray into the system horizontally and secure the latch into place.



Hardware Requirements and Precautions

- 1. Computers or servers with SATA I & SATA II & SATA III.
- 2. Hard drive with SATA I & SATA II & SATA III.
- 3. You are strongly advised to set the storage mode (the default is the Independent mode) before using the iR2321.
- 4. The product needs to be restarted after adding or changing the RAID mode, and the update is guaranteed to be the new RAID mode.
- 5. The product allows the user to simultaneously utilize two hard drives manu factured by different companies. However, if the user expects better efficiency, we strongly recommend the users to use hard drives manufactured by the same manufacturer.
- 6. Please make sure that the two hard drives are free from bad blocks or defects prior to installation in order to avoid system crashes or data loss.
- 7. The actual storage capacity of iR2320 recognized by the system may differ from the total capacity stated on the hard drives combined once the drives have been formatted
- 8. It is highly recommended for users to back up important data contained within the iR2321 on a regular basis or whenever the user feels necessary to a remote or a separate storage device. Stardom will not be responsible for any lost of data caused during the use of the unit or the recovery of the data lost.
- 9. For initial setup, it is advisable to utilize two fresh hard drives that are identical inbrand and model. In the event that a hard drive is not brand new and is not detected during the RAIDbox boot process, please connect the hard drive to the computer individually. Proceed to clear its sectors through the operating system and reformat it (for specific steps, consult the operating system's instructions) before reintroducing it into the RAIDbox for use.

Thank you for choosing RAIDON's product.

The information provided in this manual was checked before publication, but the actual product specifications may have changed before shipping; Latest product specifications and updates can be found at www.RAIDON.com.tw or through your sales representative. No separate notifications will be provided by our company.

If you have any questions about RAIDON products or would like to receive the latest product information, instruction manuals, or firmware, please contact Supporting@raidon.com.tw for assistance.

RAIDON is one brand under RAIDON TECHNOLOGY, INC.

All product-related content in this manual are copyrighted by RAIDON TECHNOLOGY, INC.